

For accurate measurements, choose a location that is not subject to direct weather elements. An ideal location is out of direct sunlight, on the North side of a building or in a shady spot.

Hang thermometer from a long nail, or screw (not included) with the built in key hole on the back.