

Equity[®]
QUARTZ Travel ALARM CLOCK
OPERATING INSTRUCTIONS
MODEL # 20085

FEATURE

1. Bright blue backlight on demand
2. Protective cover for travel
3. 4 minute repeating snooze
4. Ascending alarm
5. Accurate quartz movement
6. Requires one (1) "AA" battery (not included)

BATTERY

This model requires one "AA" battery (not included). To install the battery, remove the battery door (D) located on the back of the clock. Insert one "AA" battery as indicated by the polarity symbols (+/-) marked on the inside of the battery compartment. Replace the battery door. If the clock does not activate after inserting the battery, check to make sure the battery is fresh and properly installed.

If the clock does not operate, or steadily loses time, or if the alarm sounds weak, the battery is low and should be replaced.

SETTING THE TIME

Turn knob (C) in the direction of the arrow to set the hour and minute hands to the correct time.

SETTING THE ALARM TIME

Turn knob (B) in the direction of the arrow until the alarm set indicator on the front of the clock is set to the desired alarm time. Now, slide the Alarm On/Off switch (A) up to the "⏰" position. The alarm will sound at the preset time.

E. SNOOZE

The alarm can be stopped and repeated again four (4) minutes later when the Snooze/Light button is depressed. This snooze function can be repeated again and again. To stop the Alarm/Snooze, slide the Alarm On/Off switch (A) down to the "🔕" position.

BLUE BACKLIGHT DIAL

The dial can be illuminated at any time by pressing the Snooze / Light button, and will stay illuminated for four (4) seconds, then automatically fade. The display will also illuminate if you press the Snooze/Light button at the time the alarm sounds.

Two Year Warranty:

Equity products are warranted for two years from the date of consumer purchase against defects on material and workmanship. During this period such defects will be repaired, or the product will be replaced at Equity's option, without charge. This warranty does not cover damage caused by misuse or negligence. ALL IMPLIED WARRANTIES, INCLUDING BUT NOT LIMITED TO IMPLIED WARRANTIES OR FITNESS AND MERCHANTABILITY, ARE LIMITED IN DURATION TO A PERIOD OF TWO YEARS FROM THE DATE OF PURCHASE. Some states do not allow limitations on how long an implied warranty lasts so the above limitation may not apply to you. This warranty gives you specific legal rights and you may also have other rights which vary from State to State.

If your clock is not working, send it with a letter explaining the problem and \$5.00 for postage and handling to:

Equity by La Crosse.


Warranty Department.

2830 26th St. S.

La Crosse, WI 54601

Made in China

www.equitybylacrosse.com/support



Printed in China