


POP-UP PROJECTION ALARM CLOCK

12:34



MODEL: 616-1950
DC:012720

POP-UP PROJECTION ALARM CLOCK OVERVIEW



BOTTOM & BACK VIEW

POWER UP

1. Insert the 5.0 volt power cord into an outlet, then into the back of your clock.
2. **Optional:** Install 2-AAA batteries into the bottom of your clock for back up power supply.

SETTINGS

- Hold the **SET** button to enter the Settings Menu.
- Press the + or – button to adjust the values.
- Press the **SET** button to confirm adjustments and move to the next item.

Note: Press the **SNOOZE/LIGHT** button at any time to exit.

Settings Menu Order:

- Language: English | Español
- Beep: ON | OFF
- Hour
- Minutes
- Year
- Month
- Date
- Fahrenheit | Celsius
- Snooze Duration

Language: Whichever language is selected, the following instructions and weekday will be presented in that language

Weekday: The Weekday will set automatically when Year, Month and Date are set.

ALARM SETTINGS

Set Alarm Time

1. Hold **ALARM** for to enter alarm settings.
2. Press + or – to adjust values.
3. Press the **ALARM** button to confirm adjustments and move to the next item. The alarm is active when set.

Activate/Deactivate Alarm:

- Press the **ALARM** button once to view alarm time.
- While viewing the alarm time, press **ALARM** again to activate or deactivate the alarm.
- When active, the Alarm Icon  will show, and will disappear when deactivated.
- Press **ALARM** button to stop a sounding alarm for 24 hours.

Snooze

- When the alarm sounds, press the **SNOOZE/LIGHT** button to snooze the alarm for preselected duration.

NAP TIMER

Setting Nap Durations

- Hold the **NAP** button for to set nap duration.
- Press + or – to adjust values and **NAP** again to confirm.

Start Nap Timer

- From the main screen, press the NAP button to start the nap countdown.
- Press any button except **SNOOZE/LIGHT** to turn off the Nap timer.

DISPLAY SETTINGS

Weekday or Calendar Display

- Press the – button to select calendar display.

WEDNESDAY

Weekday Display

WED 10-25

Calendar Display


Backlight Intensity:

- Press the **SNOOZE/LIGHT** button to adjust (4 levels or OFF).

PROJECTION

Projection Arm:

- Push the Pop Up Projection Arm to view your projected time.
- Adjust the arm forward and backward until the projection is in your desired location on your wall or ceiling.



Projection Intensity:

- Press the **ROTATION** to adjust (4 levels or OFF).


Projection Image Rotation:

- Hold the **ROTATION** button for to rotate your projected image in 90° increments.

USB CHARGING PORT


There is a 1 Amp USB charging port on the side of your clock.

- Connect your device's USB charging cable (not included) to the USB charging port.
- Charging times will vary.
- USB Power Output: 1A maximum current.
- Charge 1A devices or devices that are self-regulating.
- The USB Charging Indicator will display a flashing lightning bolt when a device is charging, and a full battery when a device is fully charged.



FOLD DOWN LEGS

For viewing at higher angles, try fully opening the Fold Down Legs on the bottom of the alarm



WE'RE HERE TO HELP!

If you require additional support, get in touch with our friendly customer support team based out of La Crosse, WI.

Phone: 1-608-782-1610

Online: bit.ly/contact_techsupport

Our knowledgeable customer support team is available:
Monday-Friday, 8am-6pm CST.

JOIN THE CONVERSATION

Ask questions, watch detailed setup videos, and provide feedback on our social media outlets!



SPECIFICATIONS

Power: 5V Power Cord HX06-0501200-AU-001 Optional 2 "AAA" batteries for backup.

Indoor Temperature: 32 °F to 122 °F (0 °C to 50 °C)

Indoor Humidity: 10% RH to 99% RH

WARRANTY INFO

La Crosse Technology, Ltd. provides a **1-year limited time warranty** (from date of purchase) on this product relating to manufacturing defects in materials & workmanship. La Crosse Technology, Ltd., 2830 S. 26th St., La Crosse, WI 54601

For Full Warranty Details, Visit: www.lacrosstechnology.com/support

CARE + MAINTENANCE

- Do not mix old and new batteries.
- Do not mix Alkaline, Lithium, standard, or rechargeable batteries.
- Always purchase the correct size and grade of battery most suitable for intended use.
- Clean the battery contacts and also those of the device prior to battery installation.
- Ensure the batteries have with correct polarity (+ / -).
- Remove batteries from equipment that will not be used for an extended period.
- Promptly remove expired batteries.

FCC STATEMENT

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

CAUTION!

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

All rights reserved. This manual may not be reproduced in any form, even in part, or duplicated or processed using electronic, mechanical or chemical process without the written permission of the publisher.

This booklet may contain errors or misprints. The information it contains is regularly checked and corrections are included in subsequent editions. We disclaim any responsibility for any technical error or printing error, or their consequences. All trademarks and patents are recognized.

WARNING: This product can expose you to chemicals including styrene, which is known to the State of California to cause cancer. For more information go to: www.P65Warnings.ca.gov