

## REMOVE (SNAP) HANGER BEFORE USE

### Mounting Location:

For accurate measurements, place the rain gauge in an open area away from roof lines or water runoff.

### Mounting Options/Instructions:

- 1 – Use screw or nail to mount the rain gauge on a post or fence
- 2 – Press stake into ground.