


Quartz clock Model 87784 Operating Manual



Battery:Insert one new AA Alkaline battery according to the

polarity marked in the battery compartment

Adjust date change: Turn the time set konb clockwise until
the date changes, this indicates midnight.

Day set: While looking at the clock turn the day set board
counter clockwise to the desired day.

Date set: While looking at the clock turn the date set board
counter clockwise to the desired date.

Time set:

Time set:

If the current time is before 12:00 noon, turn the time set knob clockwise to the desired time.

If the current time is affer 12:00 noon, turn the hands past 12

o'clock again then to the desired time.

This clock will be accurate to within a few minutes per year, Should the timekeeping suddenly fluctuate, replace the battey

Note: For best performance, battery should be replaced at least once a year to maintain the best running accuracy. Ensure that that battery used is new and the correct size.

TWO YEAR WARRANTY (U.S.A.)

Equity products are warranted for two years from the date of consumer purchase against defects in material and workmanship. During this period such defects will be repaired, or the product will be replaced at Equity's opti on, without charge. This warranty does not cover damage caused by misuse or negligence. ALL IMPLIED WARRANTIES, INCLUDING BUT NOT LIMITED TO IMPLIED WARRANTIES OR FITNESS AND MERCHANTABILITY, ARE LIMITED IN DURATION TO THE PERIOD ENDING ONE YEAR FROM THE DATE OF PURCHASE. Some states do not allow limitations on how long an implied warranty will last so the above limita ton may not apply to you. This warranty gives you specific legal rights and you may have other rights which vary from state to state.

If your clock isn't working, send it with a letter explaining the problem and \$5.00 for postage and handling to:

Equity Warranty Dept 2817 Losey Blvd. So. La Crosse WI 54601



Always purchase the correct size and grade of battery most suitable for the intended use. Replace all batteries of a set at the same time. Clean the battery contacts and also those of the device prior to battery installation. Ensure the battery installed correctly with regard to polarity (+and -). Remove battery from equipment with is not to be used for an extended period of time. Remove used batteries promptly. Please help in preservation of the environment and return used batter y to an authorized depot.



钢刀大小100MM*147mm