

La Crosse®

CUBE TIMER



Timer OFF
(0 on top)




Timer 5 Minutes
(5 on top)

Models: 919-186-60WH & 919-186-30BLK

DC: 081618

Check out our SUPPORT tabs: bit.ly/919-186-60wh & bit.ly/919-186-30blk



Page 2

ACTIVATE/DEACTIVATE CUBE TIMER

1. Install 2 AAA batteries according to polarity markings.
2. Move ON/OFF Switch to ON position.
3. Select your timer duration by flipping the cube until you see your desired time on top. The countdown will begin automatically.



Page 3

4. To stop the timer, flip the cube so the 0 is on top.



5. When not in use, make sure to move the ON/OFF Switch to the OFF position to conserve battery power.

Page 4

ALARM VOLUME (OFF-LOW-HIGH)

- Adjust your alarm volume using the slide switch located under the batteries inside the battery compartment. This can be set to HIGH, LOW, or OFF.



OFF



LOW



HIGH

ALARM DURATION

- The default alarm duration is 30 seconds, after which it will shut off automatically.

- Press the Pre-AI button to give out a 10 second warning. An indicator will appear to the right of the minutes when Pre-AI is activated.

LED BUTTON

- The red LED light is set to on by default, and will stay on to indicate an active timer.
- Press the LED button to turn this “min” light ON or OFF.

Note: When manipulating the timer, you'll hear movement inside. This is the inner tilt sensor adjusting your timer's LCD orientation.

CARE + MAINTENANCE

- Do not mix old and new batteries
- Do not mix Alkaline, Lithium, standard, or rechargeable batteries
- Always purchase the correct size and grade of battery most suitable for intended use
- Clean the battery contacts and also those of the device prior to battery installation
- Ensure the batteries have the correct polarity (+ / -)
- Remove batteries from equipment that will not to be used for an extended period
- Promptly remove expired batteries.

SPECIFICATIONS

Time Duration: 919-186-60WH Preset 5, 15, 30 or 60 minutes
919-186-30BLK Preset 5, 10, 15 or 30 minutes

Power: 2-AAA batteries not included

Dimensions: 2.36 inch square (6 cm square)

WARRANTY INFO

La Crosse McCormick, LLC. provides a 2-year limited warranty (from the date of the original consumer purchase), on this product against manufacturing defects in materials and workmanship. Send \$5.00 with date and proof of purchase to the following address. Please include the model number of your product and your complete address and phone number. La Crosse McCormick, Warranty Department, 2830 26th St. St., La Crosse, WI 54601.

FCC STATEMENT

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.



WARNING: This product can expose you to chemicals including styrene, which is known to the State of California to cause cancer. For more information go to: www.P65Warnings.ca.gov