





**WIRELESS FORECAST STATION**



**TX37U-IT  
 Temperature  
 Sensor**



**BUTTONS**



## Get Started

- 1: Insert 2 fresh AA, LR6 1.5 volt batteries into the TX37U-IT sensor according to the polarity marked in the battery compartment.
- 2: Insert 3 fresh AA, LR6 1.5 volt Alkaline batteries into the forecast station according to the polarity markings.
- 3: After 5 minutes place sensor outside in a shaded location.

**Restart:** If the outdoor temperature shows dashes, remove batteries from the station & outdoor sensor. Press any button on the station 20 times. After 15 minutes, return to #1.

## Set 12/24 Hour, Temperature Units, Time

1. Hold the **SET** button to enter time set mode.
2. Press the **+** button to adjust values.
3. Press the **SET** button to confirm adjustments and move to next item.

### Settings order:

1. Hour
2. Minutes
3. 12/24 Hour Format
4. °F/°C

Press **SET** to exit, or wait 30 seconds without pressing buttons to return to the normal time display.

## Set Alarm Time

1. Hold the **ALARM** button to enter time set mode.
2. Press the **+** button to adjust values.
3. Press the **ALARM** button to confirm adjustments and move to next item.

### Settings order:

1. Hour
2. Minutes

## Activate/Deactivate Alarm

- Press the **ALARM** button. The alarm icon will show.
- Press the **ALARM** button again.
- When the alarm icon is gone, the alarm is inactive.




## Snooze

- Press the **MIN/MAX** button to activate the snooze function for 10 minutes.
- To stop the alarm completely, press any button other than the **MIN/MAX** button.

## Forecast Icons

The forecast station uses changing atmospheric pressure to predict weather conditions for the next 12-hours with 70-75% accuracy.



## Forecast Trend Arrows

The up or down arrow indicate current trends in air pressure.


**Up Arrow:** Air pressure is increasing; weather will improve.

**Down Arrow:** Air pressure is decreasing; weather will degrade.

**No Arrow:** Air pressure is stable

## Low Battery Icon

- When the low battery icon appears in the indoor reading section, replace the batteries in the forecast station.
- When the low battery icon appears in the outdoor readings section, replace the batteries in the outdoor transmitter.



## View/Reset MIN/MAX Readings

- The MIN/MAX values are constantly displayed below the temperatures.
- To reset, hold the MIN/MAX button for 5 seconds.

**Note:** The min/max values only recognize whole numbers. Therefore when reset, the min and max values may be 1-2 degrees different from current temperature.

## Position Outdoor Sensor

- Mount the outdoor sensor on a north-facing wall or in any well shaded area. Under an eave or deck rail is preferred.
- The maximum transmitting range to the wireless forecast station is over 330 feet (100 meters) in open air, not including walls, tree, windows etc.

## Specifications

### Indoor:

Temperature Range:	14.2°F to 99.9°F (-9.9°C to 37.8°C)
--------------------	--

### Outdoor:

Temperature Range:	-39.8°F to +139.8°F (-39.9°C to 59.9°C)
--------------------	--

Distance:	Over 330 ft. (100 meters) RF 915MHz (open air)
-----------	---

Interval:	About every 4 seconds
-----------	-----------------------

### Power:

Wireless Forecast Station:	3-AA, IEC, LR6 batteries (not included)
----------------------------	--

TX37U-IT Sensor:	2-AA, IEC, LR6 batteries (not included)
------------------	--

### Battery Life:

Wireless Forecast Station:	Over 12 months
----------------------------	----------------

TX37U-IT Sensor:	Over 12 months
------------------	----------------

### Dimensions:

Wireless Forecast Station:	5.33" x 1.10" x 5.56" (135.4 x 28 x 141.4mm)
----------------------------	---

TX37U-IT Sensor:	1.5" x 0.83" x 5.05" (38.2 x 21.2 x 128.3mm)
------------------	---

## Care and Maintenance

- Do not mix old and new batteries
- Do not mix Alkaline, Standard, Lithium or Rechargeable Batteries
- Always purchase the correct size and grade of battery most suitable for the intended use.
- Replace all batteries of a set at the same time.
- Clean the battery contacts and also those of the device prior to battery installation.
- Ensure the batteries are installed with regard to polarity (+ and -).
- Remove batteries from equipment which is not to be used for an extended period of time.
- Promptly remove expired batteries.

## Warranty and Support Information

La Crosse Technology, Ltd. provides a 1-year limited time warranty (from date of purchase) on this product relating to manufacturing defects in materials & workmanship.

**View full warranty details online at:**

[www.lacrossetechnology.com/warranty\\_info.pdf](http://www.lacrossetechnology.com/warranty_info.pdf)

**Before returning a product, please contact our friendly customer support with questions or visit our online help:**

La Crosse Technology, Ltd  
2830 26<sup>th</sup> Street S.  
La Crosse, WI 54601

**Contact Support:**

1-608-782-1610

**Product Registration:**

[www.lacrossetechnology.com/support/register](http://www.lacrossetechnology.com/support/register)

**Online Product Support:**

[www.lacrossetechnology.com/support](http://www.lacrossetechnology.com/support)

**Protected under U.S. Patents:**

5,978,738 | 6,076,044 | RE43903



## FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device must not be co-located or operating in conjunction with any other antenna or transmitter.

**Operation is subject to the following two conditions:**

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

**Caution!**

The manufacturer is not responsible for any radio or TV interference caused by unauthorized changes or modifications to this equipment. Such changes or modifications could void the user authority to operate the equipment.

All rights reserved. This manual may not be reproduced in any form, even in part, or duplicated or processed using electronic, mechanical or chemical process without the written permission of the publisher.

This booklet may contain errors or misprints. The information it contains is regularly checked and corrections are included in subsequent editions. We disclaim any responsibility for any technical error or printing error, or their consequences. All trademarks and patents are recognized.

**Canada Statement**

This device complies with CNR Industry Canada license -exempt devices.

Operation is subject to the following two conditions:

- (1) This device may not cause interference; and
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.